


rensair

INSTRUCTION MANUAL



Hospital-Grade Air Purifier **MODEL: Q01B**

This appliance contains a UV-C emitter.

Unintended use or damage to the housing may result in the escape of UV-C light, which in small doses may cause harm to eyes and skin.

Appliances that are obviously damaged should not be operated.

Servicing and replacement of the UV-C emitter and the HEPA 13 filter is only permitted to be carried out by authorised service personnel and is not to be attempted by the user.

Read the instructions prior to servicing the appliance. Disconnect from supply when moving or servicing the appliance.

When stored, used and maintained in accordance with its Instruction Manual (also available on www.rensair.com website), the Rensair air purifier has been scientifically proven by independent third parties to effectively reduce microorganisms, including bacteria, viruses, moulds and yeasts from the air. The maximal capacity of the air cleaner is 560 m³ per hour.

RENSAIR MAKES NO WARRANTIES, REPRESENTATIONS OR GUARANTEES, WHETHER EXPRESS OR IMPLIED, THAT THE RENSAIR AIR PURIFIER ERADICATE VIRUSES, BACTERIA, POLLEN, MOULD, ALLERGENS, ODOURS, OR OTHER PATHOGENS FROM THE SURROUNDING ENVIRONMENT ENTIRELY.

RENSAIR EXPRESSLY DISCLAIMS ALL LIABILITY EXCEPT TO THE EXTENT DESCRIBED IN THE RENSAIR STANDARD TERMS AND CONDITIONS OF SALE.

READ ALL INSTRUCTIONS AND SAFETY INSTRUCTIONS BEFORE USING THIS APPLIANCE.

Basic precautions should always be followed when using an electrical appliance. Furthermore:

TO REDUCE THE RISK OF ELECTRIC SHOCK, INJURY or FIRE:

- This Rensair appliance is only suitable for indoor dry locations. Do not use on wet surfaces or expose it to any water.
- Do not pull or stretch the mains cable. The use of an extension lead is not recommended. Keep the cable clear from any heat. The cable should not be placed under any floor coverings or in any places of high traffic where it might cause a tripping hazard.
- Do not pull the cable to unplug the appliance. To disconnect the plug, pull on the plug and not the cable wire. Unplug from the wall socket when the appliance is not being used for an extensive period of time.
- A Rensair appliance with a damaged plug or cable should not be used. Contact Rensair support which is detailed on the www.rensair.com website.
- Do not touch the appliance or the plug with wet hands.
- A Rensair appliance should only be utilised as shown in the Instruction Manual.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- In the unlikely event that the appliance is not working, do not try and fix it or attempt to use it again. Contact Rensair support which is detailed on the www.rensair.com website.
- If the supply cord is damaged it must be replaced by the manufacture, its service agent or similarly qualified persons in order to avoid a hazard.
- Keep all objects clear and free of all openings and air vents, including those for air intake and air outflow. The appliance should not be used should any vents be blocked or damaged.
- Do not use near any heat emission units or sources of heats, including fireplaces, naked flames, stoves, or strong radiators.
- Ensure that no person leans or sits on the appliance, or that any object is left on top of the appliance.
- Keep all animals away from the Rensair appliance at all times.
- Choking hazard - This remote control unit contains a battery. Keep the remote control away from children. Do not swallow the battery. If the battery is swallowed seek medical advice immediately.

MAINTENANCE WARNINGS

- The appliance should be unplugged before any maintenance is undertaken.
- No lubricants, cleaning agents or liquids should be used on this appliance.
- Maintenance and cleaning should only be carried out the authorised service agent.
- All maintenance should be done in accordance with the instructions in the Instruction Manual.

WARNING THE APPLIANCE CONTAINS MAGNETS.

- Credit cards, electronic storage media and computers may be affected by magnets and should be kept away from the appliance.
- Defibrillators and Pacemakers could be affected by magnetic fields. Anyone who has a fitted defibrillator or pacemaker should avoid coming to close proximity to the appliance.


KEEP THIS INSTRUCTION MANUAL IN A SAFE PLACE CLOSE TO THE RENSAIR APPLIANCE AT ALL TIMES AND ENSURE THAT ALL USERS HAVE READ THEM BEFORE THEY OPERATE THE RENSAIR UNIT.

BEFORE USING THE APPLIANCE, TAKE NOTE OF ALL CAUTIONARY MARKINGS IN THIS INSTRUCTION MANUAL AND THOSE DEPICTED ON THE APPLIANCE.


Voltage 220-240V~ 50Hz - Output power: 250W - Ultraviolet lamp: 18W

Description

1. Control panel
2. Dust filter x 4
3. Air inlet perforations
4. Air outlet perforations
5. Electrical plug
6. Wheels
7. Remote control



Control Panel





ON/OFF

Press to switch on/off. When switched on, the unit will start in AUTO mode. As the sensors determine the air quality, the fan speed will be set accordingly. **NOTE: The UV-C lamp will be turned on by default.** Once the air quality is deemed satisfactory, the unit will automatically switch to stand-by mode (under normal conditions, the unit will run for approx. 30 minutes prior to switching to stand-by). For further air purification, operate the unit manually.

Lock the control settings: In order to lock the keys of the panel, press the on/off button and hold it down for 5 seconds. To unlock: Repeat. Once locked, the unit can be operated with the remote control.



FAN SPEED

Press to set the fan speed: from 1 (quiet = 300m³/h) to 3 (max. intensity = 560m³/h).



UV-C LAMP CONTROL

Press to manually turn UV-C lamp on or off.



TIMER BUTTONS



Press the buttons to preset the operating time: + to increase, - to decrease (default timer duration is 8 hours). The timer can be in- or decreased by 30 minutes intervals for up to 24 hours of operation. The LCD screen displays the remaining time.



RESET BUTTON

NOTE: Should only be used when the unit is serviced. Pressing the button and holding it down for 5 seconds to resets the memory of the filter life indicator.


Remote Control

Insert two batteries. Make sure to insert the batteries according to the polarities indicated on the remote control.

Choose the function buttons corresponding to the buttons on the control panel on the Rensair air purifier.



LCD Display



Auto

Indicates AUTO mode when lit. This is the default mode when the unit is first switched on.



Fan speed, 1(standard) to 3(highest capacity).



UV-C lamp on/off indicator. The UV-C lamp will be on by default. It is recommended to keep the UV-C lamp turned on for highest air purification effectiveness.

Timer

Time left will only be indicated when timer function is turned on, otherwise the unit will display the temperature in the room.

Temp

NOTE: *If the unit has been running for a while, it may show a slightly warmer temperature due to the unit itself being warmer; this is perfectly normal.*



The Air Quality Indicator shows the quality of air based on number of particles in the air entering the unit: The fewer bars, the better. The Rensair Air Purifier will operate continuously when in AUTO mode if the air quality is not satisfactory.




The Service Indicator displays the remaining life of the filter. When bars light up all the way to the illustration on the right, it is time to service the unit. Please check the status of the UV-C lamp and filter when the service indicator is full. They must be replaced when it lights on 4 times.

Maintenance

NOTE: *Always unplug the unit when cleaning or carrying out maintenance. As an added safety feature, the power will automatically switch off when the unit is tilted.*

Cleaning the dust filters:

Please make sure the power is cut off. Remove all four filters by pressing the small clip button and lifting them up. If possible shake dust off outdoors. Use a vacuum cleaner to remove finer dust and use mild soap and water to wash them. Make sure the filters are completely dry before reinserting them.



Cleaning the main body:

Use a soft cloth, damp if necessary. **CAUTION:** Do not use alcohol, gasoline, thinner, acid, or any other substances which could damage the surface of the main body. No water or other liquid is permitted inside the main body.

Replacing filter and UV-C lamp:


NOTE: We recommend that you contact your service agent in order to carry out the servicing of the unit. For instructions, please follow the steps below - Always unplug the unit when cleaning or carrying out maintenance. As an added safety feature, the power will automatically switch off when the unit is tilted.

Turn the unit upside-down and place on a soft surface, e.g. a mat or a carpet to protect the display. Unscrew the four bolts from the base and remove the filter by lifting it out, holding the rings at the base of the filter:



The UV-C lamp can be taken out by pressing the lamp holder (1) firmly on the sides.

Once the holder 'clicks' free, the lamp (2) and the holder (1) can be carefully removed from its socket by pulling upwards. Only use original Rensair parts to avoid damaging the Rensair air purifier.



Re-assemble the unit in reverse order. Be careful not to damage the UV-C lamp when putting the filter back in place.

After assembling, plug in the Rensair air purifier and press the RESET button, holding it down for 5 seconds. This will ensure that the Service Indicator is reset.



RENSAIR

Cleanstar Pty Ltd

ABN: 51 121 002 104 ACN: 121 002 104
59 Radford Road, Reservoir VICTORIA 3073
Phone: (03) 9460 5655 Fax: (03) 9460 5666

Email: sales@cleanstar.com.au Web: www.cleanstar.com.au www.hepaairpurifier.com.au

CONDITIONS OF WARRANTY

This document outlines the terms and conditions of warranty for your Cleanstar/Rensair product. This is an important document that should be kept with your proof of purchase documents in a safe place for future reference should you require service for your product.

Thank you for purchasing your new Cleanstar/Rensair Air Purifier (Model: Q01B). We are confident this product will give you trouble-free use and excellent service, provided the operator uses and maintains the product in accordance with the Instruction Manual. Please read the Instruction Manual carefully before using the product for correct operation and maintenance procedures, and store it in a safe place for future reference.

1. This is a parts and labour warranty against faulty or defective parts, materials or workmanship in manufacturing, when the product is used and operated in accordance with the Instruction Manual.
2. This product carries a 2 year warranty period that commences from the original date of purchase by the first user/purchaser, and is not transferable.
3. This warranty only applies to products purchased and used in Australia and/or New Zealand.
4. At all times during the warranty period, Cleanstar shall, at its sole discretion, determine whether repair, replacement or refund will apply if the product has a valid warranty claim applicable to it.
5. The repair or replacement of the product under this warranty does not extend the original period of warranty.
6. Please note that this warranty will be voided in the following cases (which are not exhaustive) and the warranty does not apply to the cost of replacing any parts of the product resulting from:
 - Accidental damage;
 - Normal wear and tear;
 - Neglect, misuse or physical abuse by the operator, including failure to properly maintain or service;
 - Any alterations, modifications or tampering with the product without the prior written consent of Cleanstar;
 - Incomplete or improper installation;
 - Incorrect, improper or inappropriate operation;
 - Insect or vermin infestation;
 - Power surges, electrical storm damage or incorrect power supply/voltage;
 - Excessive use or use for which this product has not been designed;
 - Failure to comply with the operating instructions contained in the Manual supplied with the product;
 - If the product is rented;
 - If the product was serviced or repaired by anyone other than Cleanstar, or one of Cleanstar's Authorised Service Agents (ASA). Cleanstar is unable to accept any responsibility under this warranty for any repair work not carried out by an ASA or from the use of non-genuine parts.
7. This warranty does not cover service calls, travelling time or consumable parts such as filters, UV lamps, batteries and other like consumable items, unless defective in manufacture.
8. Please retain your original proof of purchase which will be required before you can make a claim under this warranty. If proof of purchase can not be provided at the time of a warranty claim or service, any work carried out on the device is chargeable.
9. Any transportation and delivery costs involved in the repair of defective parts shall be borne by the claimant. In all instances, unless the product is transported by Cleanstar or a Cleanstar authorised representative, the product is transported at the owner's cost and risk while in transit to and from Cleanstar or its ASA.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits conferred by this warranty are in addition to other rights and remedies under law in respect of the product to which this warranty relates.

TO INQUIRE ABOUT MAKING A CLAIM UNDER THIS WARRANTY, PLEASE FOLLOW THESE STEPS:

- a) carefully check the Instruction Manual and the terms of this warranty;
- b) have the name and model number of the appliance available;
- c) have the proof of purchase available (ie. invoice, receipt, etc) showing where the appliance was purchased from and the date of purchase;
- d) call Cleanstar on (03) 9460 5655 to speak to one of our customer service staff.